

OPERATION FOR SOFTWARE INSTALL

SUPPORTS THE FOLLOWING OPERATING SYSTEM(English and Chinese):

- WINDOWS 98SE
- WINDOWS ME
- WINDOWS 2000
- WINDOWS XP(32 & 64 BIT)
- WINDOWS SERVER 2003(32 & 64 BIT)
- WINDOWS SERVER 2008 / 2008(32 & 64BIT)
- WINDOWS VISTA(32 & 64 BIT)
- WINDOWS 7(32 & 64 BIT)

Step-By-Step:


1. Install PC-LINK software.




2. Install USB driver.



3. Restart PC.
4. Put the USB cable to the PC USB port.
5. PC detected the COM.



6. Run the Anemometer software.
7. Set the right COM number in the software.



8. Connect with USB cable and meter.
9. Turn on the meter and act the Anemometer function.
10. Press the start button in the Anemometer software.
11. If in the Windows Vista/Windows 7 system, please run as administrator.