

OPERATION FOR SOFTWARE INSTALL

SUPPORTS THE FOLLOWING OPERATING SYSTEM(English and Chinese):

- WINDOWS 98SE
- WINDOWS ME
- WINDOWS 2000
- WINDOWS XP(32 & 64 BIT)
- WINDOWS SERVER 2003(32 & 64 BIT)
- WINDOWS SERVER 2008 / 2008(32 & 64BIT)
- WINDOWS VISTA(32 & 64 BIT)
- WINDOWS 7(32 & 64 BIT)

Step-By-Step:


1. Install HP-90K software





2. Install USB driver



3. Restart PC.
4. Put the USB cable to the PC USB port.
5. PC detected the COM.



6. Run the HP-90K software.
7. Set the right COM number in the software.



8. Connect with USB cable and meter.
9. Turn on the meter and act the HP-90K function.
10. Press the start button in the HP-90K software.
11. If in the Windows Vista/Windows 7 system, please run as administrator